

AIRCRAFT PARKING / DOCKING CHART- ICAO

TWR 118.700
GND 118.525

ROVANIEMI, FINLAND

025°49'

025°50'

66° 34'

66° 34'

RWY details, see EFRO AD 2.12
ACFT stand details, see EFRO AD 2.20
APN details, see EFRO AD 2.8
TWY details, see EFRO AD 2.8 and AD 2.15

↑
VAR 11.9° E 2020
Annual Change +0.2°

ELEV in FT

ATC SER BDRY

K1

VOR/DME

Fire Station

TWR

ARP
66°33'42" N
025°49'51" E

Hot Spot 3

Helicopter alighting area

Compass Check Point

General Aviation Parking Area

Fuel

APN

ACL 636

6B

4B

5

6C

7B

8C

8B

9

6

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

ATC SER BDRY

R LIL

Terminal

Hangar

Hot Spot 3
Observe taxiway lights separating
TWY T and civil apron.

LEGEND

22 — ACFT stands and TWY centre line or lead-in line

• TWY LGT


••• Closure LGT system
Used only in low visibility conditions

CHG: ADDN ACFT stand 8C

VOR Check Point
ROI 117.700 MHZ

ATC SER BDRY

TO ROVANIEMI



66° 33'

66° 33'

025°49'

025°50'